



Prime Teak Oil

Description: Maintenance oil for exterior wood and garden furniture

Color: Clear, Burma, Mustard, Brown, Natural

Gloss: Natural look

Type: Oil-based

General Features:

- Preserves the natural appearance of wood and penetrates deeply
- Clear and 4 translucent color options
- Water repellent
- Easy maintenance
- Lead-free
- Ready to use

Packaging Size: 0,750 L., 2,5 L., 15 L.

Where to Use:

- For exterior wood and garden furniture
- Suitable for all exterior wood of boats above the waterline

Product Data:

Solid Content (% weight):	40,05 ± 1
Viscosity (DIN4, 20°C):	11" ± 1
Density (g/cm ³):	0,85 ± 0,02
VOC (g/L):	502
Application Method:	Brush or cloth
Shelf Life (5-35°C):	2 years for unopened can
Number of Coats:	1 or 2 coats
Coverage (m ² /L):	10-12 m ² on softwoods, 15-18 m ² on hardwoods (depending on wood type and application method)
Drying Time (at 20°C and 40-65% relative humidity):	Touch Dry: 4 hours Complete Dry: 24 hours
Thinning:	Ready to use, does not require thinning.



Surface Preparation:

- Remove any dirt, oil and wood dust from the surface
 - **New Wooden Floors:**
 - Sand the surface with sandpaper #80/120.
 - Thoroughly clean the generated dust.
 - **Old Uncoated Wood Surfaces:**
 - Sand the weathered surface with sandpaper #80/120.
 - **Coated Wood Surfaces:**
 - Do not apply the product directly on pre-coated surfaces.
 - Remove the old paint/varnish from the surface completely with a sandpaper.
 - Thoroughly clean the generated dust

Application:

- The product is ready to use and does not require thinning.
- Stir the product thoroughly before use.
- Apply the product in 1 coat by a brush or cloth and remove the excess oil by cloth for the best result.
- Wait 24 hours for complete dry.

Maintenance (when the same product had been used before):

- Do not apply the product directly on pre-coated surfaces.
- Clean the wood surface completely from dirt and oil and perform a slight sanding.
- Thoroughly clean the generated dust.
- Repeat same process as described in "Application".
- Maintenance should be repeated every season.

Instructions:

- FOR EXTERIOR USE ONLY.
- Keep product closed when not in use.
- The general application temperature of the product is between 15o C to 25o C at a relative humidity range of 40-65%.
- The moisture content of the wood should be max. 20%.
- Do not apply the product under direct sunlight or rain.
- To provide a long lifetime protection against decay, apply Prime Wood Preserver on untreated softwoods and wait 24 hours before applying Prime Teak Oil.
- The product should be stored at temperatures between 5°C to 35°C.
- Painting tools should be cleaned with mineral spirits after the application.

Safety Precautions:

- **OIL SOAKED FABRIC CAN BE SELF IGNITING. FABRICS SHOULD BE COMPLETELY SOAKED IN WATER AND DISPOSED OF AFTER BEING USED.**
- USE WITH ADEQUATE VENTILATION.
- KEEP OUT OF REACH OF CHILDREN.
- Do not transfer contents to other containers for storage.
- Do not use empty plastic cans for other purposes.



- To avoid overexposure, open windows and doors or use other means to ensure fresh air entry during application and drying.
- Avoid contact with eyes and skin.
- Wash hands after using.
- FIRST AID: In case of eye contact, flush thoroughly with large amounts of water. Get medical attention if irritation persists. If swallowed, call Poison Control Center, hospital emergency room, or physician immediately.
- Dispose of contents/plastic cans in accordance with national regulations.
- Please refer to the Safety Data Sheet (SDS) of the product for health and safety information.