

# HEMEL<sup>®</sup> Teak Oil

**Description:** Maintenance oil for exterior wood and garden furniture

**Color:** Clear

**Gloss:** Natural look

**Type:** Oil-based

**General Features:**

- Penetrates deeply
- Nourishes and revives
- Easy maintenance
- Water repellent
- Salt water resistant
- Lead-free
- Ready to use

**Packaging Size:** 0,750 L., 2,5 L., 5 L., 15 L.

**Where To Use:**

- For exterior wood and garden furniture
- Suitable for all exterior wood of boats above the waterline

**Product Data:**

Solid Content (% weight):	42,8 ± 1
Viscosity (DIN4, 20°C):	10" ± 2
Density (g/cm <sup>3</sup> ):	0,85 ± 0,02
VOC (g/L):	482
Application Method:	Brush or cloth
Shelf Life (5-35°C):	2 years for unopened can
Number of Coats:	1 coat
Coverage (m <sup>2</sup> /L):	12-15 m <sup>2</sup> depending on wood type
Drying Time (at 20°C and 40-65% relative humidity):	Touch Dry: 4 hours Complete Dry: 24 hours
Thinning:	Ready to use, does not require thinning.

**Surface Preparation:**

- Remove any dirt, oil and wood dust from the surface.
  - **New Wood Surfaces:**
    - Sand the surface with sandpaper #80/120.
    - Thoroughly clean the generated dust.
  - **Old Uncoated Wood Surfaces:**
    - Sand the weathered surface with sandpaper #80/120 or restore wood surface using HEMEL Deck Restorer.
  - **Coated Wood Surfaces:**
    - Do not apply the product directly on pre-coated surfaces.
    - Remove the old paint/varnish from the surface completely with a sandpaper.
    - Thoroughly clean the generated dust.

**Application:**

- The product is ready to use and does not require thinning.
- Stir the product thoroughly before use.
- Apply the product in 1 coat by a brush or cloth and remove the excess oil by cloth for the best result.
- Wait 24 hours for complete dry.

**Maintenance (when the same product had been used before):**

- Do not apply the product directly on pre-coated surfaces.
- Clean the wood surface completely from dirt and oil and perform a slight sanding.
- Thoroughly clean the generated dust.
- Repeat same process as described in "Application".
- **Maintenance should be repeated every season.**

**Instructions:**

- FOR EXTERIOR USE ONLY.
- Keep product closed when not in use.
- The general application temperature of the product is between 15°C to 25°C at a relative humidity range of 40-65%.
- The moisture content of the wood should be max. 20%.
- Do not apply the product under direct sunlight or rain.
- To provide a long lifetime protection against decay, apply HEMEL Timbercare Aqua on untreated softwoods and wait 24 hours before applying HEMEL Teak Oil.
- The product should be stored at temperatures between 5°C to 35°C.
- Painting tools should be cleaned with mineral spirits after the application.

**Safety Precautions:**

- **OIL SOAKED FABRIC CAN BE SELF IGNITING. FABRICS SHOULD BE COMPLETELY SOAKED IN WATER AND DISPOSED OF AFTER BEING USED.**
- USE WITH ADEQUATE VENTILATION.
- KEEP OUT OF REACH OF CHILDREN.
- Do not transfer contents to other containers for storage.
- Do not use empty plastic cans for other purposes.
- To avoid overexposure, open windows and doors or use other means to ensure fresh air entry during application and drying.
- Avoid contact with eyes and skin.
- Wash hands after using.
- **FIRST AID:** In case of eye contact, flush thoroughly with large amounts of water. Get medical attention if irritation persists. If swallowed, call Poison Control Center, hospital emergency room, or physician immediately.
- Dispose of contents/plastic cans in accordance with national regulations.
- Please refer to the Safety Data Sheet (SDS) of the product for health and safety information.

**Certificates:**

- EN71-3 Toy Safety Certificate