

Hickson Decor® Aqua Breather Paint

Description: Water-based opaque exterior wood finish that allows wood to breathe

Color: Dee Sky Blue, Polar White, Red Ochre, Unlimited Color Choice (*)
 (*) NCS and RAL colors are produced on demand.

Gloss: Semi-gloss, high-gloss

Type: Water-based

General Features:

- Water repellent
- Allows wood to breathe
- Opaque wood finish
- Durable and resistant to exterior weather conditions
- UV resistant
- Lead-free
- Does not crack, peel or blister
- Environmentally friendly
- Ready to use

Packaging Size: 1 L., 2,5 L., 5 L., 15 L.*

Where To Use:

- Suitable for all exterior wood except floors
- Doors and window joinery
- Shutters
- Claddings
- Fences
- Pergolas
- Balcony railings
- Roof fringes
- Restorations

Product Data:

Solid Content (% weight):	52,6 ± 1
Viscosity (DIN6, 20°C):	70" ± 5
Density (g/cm³):	1,29 ± 0,02
VOC (g/L):	28
Application Method:	Brush
Shelf Life (5-35°C):	1 year for unopened can
Number of Coats:	2 coats
Coverage (m²/L):	5 m² with 2 coats depending on wood type
Drying Time (at 20°C and 40-65% relative humidity):	Recoat: 16 hours Complete Dry: 16 hours
Thinning:	Ready to use, does not require thinning. (At very high temperatures 10% drinking water may be added).

Surface Preparation:

- Remove any dirt, oil and wood dust from the surface.
- Apply HEMEL Acrylic Filling Paste on nailheads, joint points, capillary cracks and depths below 3 mm.

*Upon request

- **New Wood Surfaces:**
 - Sand the surface with sandpaper #80/120.
 - Thoroughly clean the generated dust.
- **Old Uncoated Wood Surfaces:**
 - Sand the weathered surface with sandpaper #80/120.
 - Thoroughly clean the generated dust.
- **Coated Wood Surfaces:**
 - Do not apply the product directly on pre-coated surfaces.
 - Remove the old paint/varnish from the surface completely with a sandpaper.
 - Thoroughly clean the generated dust.
- The application of Hickson Decor® Aqua Universal Primer is recommended before Hickson Decor® Breather Paint, having the function of a barrier and preventing the yellowing of the last coat stain particularly at exotic and resin containing woods. If not, the surface of wood containing resins and natural oils should be cleaned with a cloth soaked in cellulosic thinner and dried out before the application.

Application:

- The product is ready to use and does not require thinning. (At very high temperatures 10% drinking water may be added).
- Stir the product thoroughly before use and check its homogeneity. Repeat this process during the application.
- Apply the product in 2 coats by brush and wait 16 hours between coats.
- Perform a slight sanding with sandpaper #180/220 between coats.
- Wait 16 hours for complete dry.

Maintenance (when the same product had been used before):

- Do not apply the product directly on pre-coated surfaces.
- Clean the wood surface completely from dirt and oil and perform a slight sanding.
- Thoroughly clean the generated dust.
- Repeat same process as described in "Application" with 1 or 2 coats depending on weathering.
- Inspect annually and maintain as required.

Instructions:

- FOR EXTERIOR USE ONLY.
- NOT SUITABLE FOR FLOORINGS.
- Keep product closed when not in use.
- The general application temperature of the product is between 15°C to 25°C at a relative humidity range of 40-65%.
- The moisture content of the wood should be max. 20%.
- Do not apply the product under direct sunlight or rain.
- Do not apply linseed oil, basecoat/primer, yacht varnish before or after Hickson Decor® Aqua Breather Paint applied surfaces.
- To provide a long lifetime protection against decay, apply HEMEL Timbercare Aqua on untreated softwoods and wait 24 hours before applying Hickson Decor® Aqua Breather Paint.
- The product should be protected from freezing and stored at temperatures between 5°C to 35°C.
- Painting tools should be cleaned with soap and plenty of warm water after application.

Safety Precautions:

- USE WITH ADEQUATE VENTILATION.
- KEEP OUT OF REACH OF CHILDREN.
- Do not transfer contents to other containers for storage.
- Do not use empty cans for other purposes.
- To avoid overexposure, open windows and doors or use other means to ensure fresh air entry during application and drying.
- Avoid contact with eyes and skin.
- Wash hands after using.
- FIRST AID: In case of eye contact, flush thoroughly with large amounts of water. Get medical attention if irritation persists. If swallowed, call Poison Control Center, hospital emergency room, or physician immediately.
- Dispose of contents/cans in accordance with national regulations.
- Please refer to the Safety Data Sheet (SDS) of the product for health and safety information.

Certificates:

- EN71-3 Toy Safety Certificate